CHEST PRESS

- 1. ADJUST SEAT POSITION SO HANDLES ARE ALIGNED WITH MIDDLE OF CHEST. ADJUST STARTING POSITION OF PRESS ARM USING PULL PIN AT TOP OF PRESS ARM.
- 2. WITH BACK FIRMLY AGAINST BACK PAD, GRASP HANDLES AND PRESS ARM AWAY FROM BODY.





WEIGHT RATIO CHART

The state of the s	Control of the second	100	
STATION	RATIO	WEIGHT	RESISTANCE
CHEST PRESS	1.25/1	10 Les.	12.5 Les.
FREE CABLE ARMS	.5/1 EACH	10 Les.	5 Les.
LEG EXT/CURL	1/1	1 O Les.	1 O Les.
HIGH PULLEY	1/1	10 Les.	1 O Les.
AB CRUNCH	1/1	1 O Les.	1 O Les.
MID ROW	1.25/1	1 🗆 Les.	1 O Les.
LEG PRESS	2/1	10 Les.	20 Les.

WARNING

THERE IS A RISK ASSUMED BY INDIVIDUALS WHO USE THIS TYPE OF EQUIPMENT. TO MINIMIZE RISK ALWAYS FOLLOW THESE RULES.

- 1) It is essential that you consult with your PHYSICIAN BEFORE BEGINNING ANY EXERCISE PROGRAM.
- INSPECT EQUIPMENT BEFORE EACH USE FOR LOOSE, WORN OR FRAYED PARTS (INCLUDING CABLES, NUTS AND BOLTS). REPLACE PARTS AT FIRST SIGNS OF WEAR (USE ONLY GENUINE BATCA REPLACEMENT PARTS). USE OF EQUIPMENT THAT IS DAMAGED, WORN, FRAYED OR NOT COMPLETELY ASSEMBLED ON A SOLID, LEVEL SURFACE MAY RESULT IN INJURY.
- 3) Make sure all adjustment pins are fully engaged before using EQUIPMENT.
- KEEP ALL PARTS OF THE BODY AND CLOTHING OUTSIDE THE PATH OF ANY MOVING PARTS OF THE MACHINE. BE ALERT TO THE POSSIBILITY OF INJURY. DO NOT BE
- MINORS AND CHILDREN SHOULD NOT BE ALLOWED TO PLAY ON OR AROUND THIS MACHINE.
- 6) IF YOU HAVE ANY QUESTIONS ON PROPER USE OR MAINTENANCE OF THIS MACHINE, DO NOT HESITATE TO CALL YOUR LOCAL BATCA FITNESS SYSTEMS DISTRIBUTOR OR,



BATCA FITNESS SYSTEMS (919) 255-1233

MAINTENANCE

Clean and lubricate weight stack guide rods regularly. Use Teflon or Silicon based lubricants (do not use oil Guide Rods

CHECK AND TIGHTEN ANY LOOSE FASTENERS ON A REGULAR

FREE CABLE CHEST PRESS

1. ADJUST BOTTOM SEAT, BACK PAD, AND STRAP HANDLES FOR DESIRED START POSITION.

AB CRUNCH

1. ADJUST BACK PAD FOR DESIRED

PRE-STRETCH/START POSITION. PLACE AB STRAP

CRUNCHING MOTION, PIVOT YOUR UPPER BODY

OVER YOUR SHOULDERS AND GRASP HANDLES.

SHOULDER PRESS

PRESS UPWARD.

1. ADJUST BOTTOM SEAT, BACK PAD, AND STRAP

2. WHILE SEATED WITH BACK FIRMLY AGAINST BACK PAD,

1. GRIP BAR WITH PALMS FACING DOWN AND A

2. Pull bar up until it is just under your chin

(ARM SHOULD BE PARALLEL TO FLOOR IN TOP POSITION).

HANDLES FOR DESIRED START POSITION.

UPRIGHT ROW

SHOULDER'S WIDTH APART.

SHOULDER SHRUG

SHOULDER'S WIDTH APART.

1. GRIP BAR WITH PALMS FACING DOWN AND A

2. KEEPING A SLIGHT BEND IN ELBOWS, RAISE

SHOULDERS UNTIL MUSCLES ARE FULLY CONTRACTED.

GRASP HANDLES AT TOP OF SHOULDERS AND

2. WITH YOUR BACK AGAINST THE PAD, IN A

2. WHILE SEATED WITH BACK FIRMLY AGAINST PAD, GRASP HANDLES AT MID CHEST LEVEL AND PRESS FORWARD.



PEC FLY

- 1. ADJUST BOTTOM SEAT, BACK PAD, AND STRAP HANDLES FOR DESIRED START POSITION.
- 2. WHILE SEATED WITH BACK FIRMLY AGAINST BACK PAD, GRASP HANDLES AND EXTEND ARMS KEEPING A SLIGHT
- BEND IN THE ELBOWS. SLOWLY PUSH THE HANDLES TOWARD THE CENTER OF

YOUR BODY.



- 1. ADJUST SEAT POSITION SO LEGS FIT SNUGLY UNDER HOLD-DOWN ROLLERS.
- 2. TAKE LAT BAR OFF HOLDER AND GRIP BOTH ENDS. WHILE SEATED, PULL BAR DOWN TO TOP OF CHEST. (KEEP BACK STRAIGHT DURING EXERCISE).



MID ROW

- 1. ADJUST SEAT POSITION SO HANDLES ON ROW ARM ARE ALIGNED WITH MIDDLE TO LOWER PART OF CHEST. ADJUST CHEST SUPPORT PAD FOR DESIRED PRE-STRETCH/START
- 2. GRASP HANDLES OF ROW ARM. WITH CHEST FIRMLY AGAINST SUPPORT PAD, PULL MID ROW ARM TOWARDS BODY.



BICEP CURL

- 1. GRIP BAR WITH PALMS FACING UPWARD AND HANDS A SHOULDER'S WIDTH APART.
- 2. WITH ELBOWS TIGHT TO YOUR BODY, CURL BAR UP UNTIL BICEPS ARE FULLY CONTRACTED.



TRICEP EXTENSION

- 1. TAKE BAR OFF HOLDER AND GRIP WITH PALMS FACING DOWN AND HANDS A SHOULDER'S WIDTH APART.
- 2. WITH ELBOWS TIGHT TO BODY, PUSH BAR DOWN UNTIL TRICEPS ARE FULLY CONTRACTED.



LEG EXTENSION

- 1. ADJUST TOP ROLLER TO HIGH POSITION. FLIP TWO SHORT ROLLERS FORWARD. ADJUST BACK PAD TO SUPPORT BACK WHILE ALIGNING YOUR KNEES WITH PIVOT POINT OF ARM. WITH LOWER ROLLER PAD IN FRONT OF ANKLES, USE PULL PIN ON ARM TO ADJUST DESIRED PRE-STRETCH/START POSITION.
- 2. LIFT AND STRAIGHTEN LEGS KEEPING A SLIGHT BEND IN KNEES. SLOWLY RETURN TO START POSTION NEVER RELEASING TENSION FROM MUSCLE.



LEG CURL

- 1. FLIP TWO SHORT ROLLERS TO REAR POSITION. ADJUST BACK PAD TO SUPPORT BACK WHILE ALIGNING KNEES WITH PIVOT POINT OF ARM. WITH BOTTOM ROLLER PAD BEHIND ANKLES, USE PULL PIN ON ARM TO ADJUST FOR DESIRED PRE-STRETCH/START POSITION KEEPING A SLIGHT BEND IN KNEES. LOWER TOP ROLLER TO FIT SNUGLY ON TOP OF SHINS. 2. CURL LEGS DOWNWARD UNTIL HAMSTRINGS ARE
- FULLY CONTRACTED.



STANDING INNER/DUTER THIGH

- 1. WRAP STRAP AROUND THIGH JUST ABOVE THE KNEE AND HOOK TO FUNCTIONAL ARM CABLE.
- ADJUST AND USE PRESS ARM FOR STABILITY. 2. OUTER THIGH: KICK LEG AWAY FROM BODY.
- 3. INNER THIGH: KICK LEG ACROSS BODY.



GLUTE KICK

- 1. WRAP STRAP AROUND THIGH JUST ABOVE THE KNEE AND HOOK TO FUNCTIONAL ARM CABLE. ADJUST AND USE PRESS ARM FOR STABILITY.
- 2. KICK LEG BACK (KEEPING A SLIGHT BEND IN KNEE) UNTIL GLUTE MUSCLE IS FULLY CONTRACTED.



- 1. USING PULL PIN BEHIND BACK PAD, ADJUST SEAT FOR DESIRED PRE-STRETCH/START POSITION.
- 2. PLANT FEET FIRMLY ON FOOTPLATE AND BACK FIRMLY AGAINST BACK PAD. PUSH FOOTPLATE AWAY FROM BODY (DO NOT LOCK KNEES).



CALF RAISE

- . USING PULL PIN BEHIND BACK PAD, ADJUST SEAT FOR DESIRED PRE-STRETCH/START POSITION.
- 2. PLANT BALLS OF FEET FIRMLY AT BOTTOM OF FOOTPLATE AND BACK FIRMLY AGAINST BACK PAD. PUSH FOOTPLATE AWAY FROM BODY KEEPING A SLIGHT BEND IN KNEES. PRESS BALLS OF FEET FORWARD UNTIL CALF MUSCLES ARE FULLY CONTRACTED.





WWW.BATCAFITNESS.COM

CABLES CHECK AND ADJUST CABLE TENSION REGULARLY.

BASED LUBRICANTS).

Upholstery Clean regularly using mild soap and water with a